

JAMMA			
Solder Side	PIN #		Parts Side
GROUND	A	1	GROUND
GROUND	B	2	GROUND
+5 VOLTS	C	3	+5 VOLTS
+5 VOLTS	D	4	+5 VOLTS
-5 VOLTS	E	5	-5 VOLTS
+12 VOLTS	F	6	+12 VOLTS
KEY	H	7	KEY
COIN COUNTER 2	J	8	COIN COUNTER 1
COIN LOCK OUT 2	K	9	COIN LOCK OUT 1
SPEAKER (-)	L	10	SPEAKER (+)
NOT USED	M	11	NOT USED
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SWITCH	R	14	VIDEO GROUND
TILT / SLAM SWITCH	S	15	TEST SWITCH
COIN SWITCH 2	T	16	COIN SWITCH 1
2P START	U	17	1P START
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P BUTTON 1	Z	22	1P BUTTON 1
2P BUTTON 2	a	23	1P BUTTON 2
2P BUTTON 3	b	24	1P BUTTON 3
2P BUTTON 4	c	25	1P BUTTON 4
2P BUTTON 5	d	26	1P BUTTON 5
GROUND	e	27	GROUND
GROUND	f	28	GROUND